




ПЦ1-2400

NO.	DESCRIPTION	SPEC	NO.	DESCRIPTION	SPEC
1	CABLE		41-6	BEARING	6000RS
2	CABLE ANCHORAGE		42	GEAR CASE COVER	
3	SCREW	ST4*12	43	BRAKE LEVER ASSEMBLY	
4	CABLE PROTECTOR		43-1	WASHER	φ5
5	SAFETY LOCKING BUTTON		43-2	SPRING	
6	SPRING		43-3	BRAKE LEVER	
7	SWITCH TRIGGER		43-4	CONNECTING ROD	
8	AUXILIARY HANDLE		43-5	BRAKE FIXING PLATE	
9	SCREW	ST4*1 6	44	TUBING	
10	REAR COWL		45	OIL PUMP COMPONENTS	
11	PROTECTIVE PLATE		46	PUMP BODY	
12	PROTECTIVE PLATE GASKET		47	OIL TANK ASSEMBLY	
13	WASHER	φ5Xφ15	47-1	SEALING RING	
14	SCREW ST5X30	ST5X30	47-2	FUEL TANK JOINT	
15	LEFT HOUSING		47-3	SPONGE	
16	LEAF SPRING		47-4	PLUG	
17	SCREW ST3X8	ST3X8	47-5	OIL TANK	
18	CARBON BRUSH		47-6	CHECK VALVE	
19	BRUSH HOLDER		47-7	O-RING	
20	MOTOR BACK BRACKET		47-8	OIL TANK COVER	
21	NUT M4	M4	47-9	POTHOOK	
22	SCREW ST3X8	ST3X8	48	DUST-PROOF SPONGE	
23	STATOR		50	SPRING	
24	MOTOR FRONT BRACKET		51	CHAIN WHEEL	
25	WASHER φ4	φ4	52	CIRCLIP	φ7
26	SPRING WASHER φ4		53	RUBBER RING	
27	NON-STANDARD SCREW M4*67	M4*67	54	SCREW	M5X20
28	BEARING 608RS	608RS	55	CHAIN PLATE FIXING PLATE	
29	ROTOR		56	BUMPER SPIKE	
30	BEARING 6000RS		57	SCREW	ST4X10
31	GEAR BOX		58	GUIDE BAR SCREW	
32	SHAFT SLEEVE		59	GUIDE BAR	
33	PINION GEAR		60	SHAFT SLEEVE	
34	NUT M8	M8	61	KNOCKOUT PLATE	
35	OUT OF THE NOZZLE		62	CIRCLING ROUND WHEEL	
36	O-RING		63	WASHER	φ 11Xφ 20X1
37	CAPACITOR		64	CIRCLIP	
38	SWITCH		65	CHAIN	
39	PUSH ROD		66	SCABBARD	
40	SPRING		67	CHAIN COVER	
41	BIG GEAR ASSEMBLY		68	CIRCLIP	φ 19
41-1	NUT M8		69	TENSIONING KNOB	
41-2	BIG GEAR		70	COMPRESS KNOB	
41-3	SHAFT SLEEVE		71	SOFT START	
41-4	BRAKE TORSION SPRING		72	INDUCTOR	
41-5	OUTPUT SHAFT				