


EA2520

| No. | Description | No. | Description |
|------|---------------------|------|------------------|
| 1 | engine | 3-4 | left box |
| 2 | gear case ass'y | 3-5 | stop button |
| 2-1 | clutch drum comp. | 3-6 | clock pin |
| 2-2 | gear case cover 1 | 3-7 | hand grip |
| 2-3 | pin B4X10 | 3-8 | spring |
| 2-4 | Bearing 6202 | 3-9 | right box |
| 2-5 | stop ring ϕ 35 | 3-10 | screw ST3.5X16 |
| 2-6 | stop ring ϕ 15 | 3-11 | screw M5X30 |
| 2-7 | gear 1 | 3-12 | cable comp |
| 2-8 | gear case cover 2 | 3-13 | tube |
| 2-9 | bearing 6201 | 3-14 | stop line |
| 2-10 | gear 2 | 3-15 | hand grip |
| 2-11 | bearing 6004 | 3-16 | spring |
| 2-12 | oil seal | 3-17 | nut M5 |
| 2-13 | gear case cover 3 | 4 | left grip |
| 2-14 | screw M5X45 | 5 | operate frame |
| 2-15 | spindle | 6 | screw M6X20 |
| 2-16 | screw M5X30 | 7 | Gear case washer |
| 2-17 | Nut M10X10 | 8 | pad washer |
| 2-18 | gear 3 | 10 | scrw M8 |
| 2-19 | screw M5X25 | 16 | allen key |
| 3 | Lever ass'y | 17 | spanner |
| 3-1 | screw ST2.9X10 | 18 | slave |
| 3-2 | Button | 19 | spanner |
| 3-3 | spring | 21 | fuel tank |

EA2520-EX-20210



Engine of EA2520

| No. | Description | No. | Description |
|------|-------------------|--------|--------------------|
| 1-1 | big nut | 1-34 | bearing 6202 |
| 1-2 | air filter cover | 1-35 | left base |
| 1-3 | air filter | 1-36 | right base |
| 1-4 | screw M5X50 | 1-37 | oil seal 15X25X7 |
| 1-5 | anti-oil board | 1-38 | fly wheel |
| 1-6 | air filter base | 1-39 | washer 10 |
| 1-7 | carburetor | 1-40 | spring washer 10 |
| 1-8 | carburetor washer | 1-41 | nut M10X1.25 |
| 1-9 | screw M5X30 | 1-42 | ignitor |
| 1-10 | air inlet | 1-43 | cable |
| 1-11 | air inlet washer | 1-44 | starter |
| 1-12 | cylinder | 1-45 | anti-heating board |
| 1-13 | screw M5X20 | 1-46 | screw M5X16 |
| 1-15 | cyliner cover | 1-47 | tank |
| 1-16 | screw M5X12 | 1-48 | washer 5 |
| 1-17 | wind board | 1-49 | anti-heating foot |
| 1-18 | spark plug | 1-50 | tank cover Ass |
| 1-19 | muffler washer | 1-50-1 | tank cover |
| 1-20 | muffler | 1-50-2 | tank cover washer |
| 1-21 | washer 8 | 1-50-3 | one way valve |
| 1-22 | screw M8X25 | 1-50-4 | inner tank cover |
| 1-23 | cylinder washer | 1-50-5 | chain upper base |
| 1-24 | piston ring 1 | 1-50-6 | chain down base |
| 1-25 | piston ring 2 | 1-51 | fuel tube Ass |
| 1-26 | piston | 1-51-1 | fuel inlet tube |
| 1-27 | cirlip | 1-51-2 | fuel outlet tube |
| 1-28 | piston pin | 1-51-3 | washer |
| 1-29 | needle bearing | 1-51-4 | fule filter |
| 1-30 | cylinder | 1-52 | clutch |
| 1-31 | key 3x13 | 1-53 | washer |
| 1-32 | pin | 1-54 | spring washer 6 |
| 1-33 | base washer | 1-55 | bolt M6X16 |