




HPC90W HPC110W

NO.	DESCRIPTION	NO.	DESCRIPTION
1	THE FOAM OF HANDLE GRIP	44	HEX BOLT M8X60
2	HANDLE	45	ENGINE AMOUNTING PLATE
3	CORD SWITCH	46	FLAT WASHER 10N
4	+ SNAP-HEAD BOLT	47	HEX NUT M10
5	HEX-NUT M6	48	HEX BOLT M6X16
6	SPRING PIN	49	SPRING WASHER 6
7	CAP NUT M8	50	RIGHT BEARING COVER
8	TENSION SPRING	51	SEAL RING
9	PIPE END CAP	52	BEARING 6309
10	HEX SUNK SCREW M8X20	53	CIRCLIP FOR HOLE 100
11	HEX BOLT M6X40	54	VIBRATION SHAFT
12	FLAT WASHER 6N	55	HEX BOLTS M10X30
13	HOOK	56	ECCENTRIC IRON
14	CONNECTION FRAME FOR HANDLE	57	CIRCLIP FOR SHAFT 45
15	HEX BOLT M10X65	58	LEFT BEARING COVER
16	SHOCK-REDUCING RUBBER RING	59	LIP OIL SEAL 30X42X7
17	SELF-LOCKING NUT M10	60	FLAT KEY
18	RUBBER GASKET	61	PULLEY
19	SEAL RING 5	62	PULLEY CIRCLIP
20	PETROL ENGINE	63	BOTTOM PLATE
21	HEX FLANGE NUT M8	64	SHOCK-REDUCING RUBBER BLOCK
22	FIXED PLATE FOR BOLT	65	HEX FLANGE NUT M10
23	ASJUSTING WASHER	66	END NUT
24	OIL DRAIN PIPE	67	WASHER
25	CLUTCH SPRING	68	SPLIT PIN 2.5 X 25
26	CLUTCH FRICTION BLOCK	69	FLAT WASHER 14N
27	CLUTCH CORE	70	5" WHEEL
28	CLUTCH BELT PULLEY	71	HEX SELF-LOCKING NUT M12
29	BEARING 6006-LS	72	HEX BOLT M10X30
30	CIRCLIP FOR SHAFT 30	73	CONNECTION ROD
31	CIRCLIP FOR HOLE 55	74	TRANSPORT FRAME
32	FLAT WASHER 8N	75	HEX BOLT M12X25
33	SPRING WASHER 8	76	RUBBER PAD
34	HEX BOLT M8X25	77	RUBBER PAD SPLINT
35	FIXED PLATE BELT COVER	78	HEX BOLT M10 X 35
36	V-BELT	101	OUTLET PIPEWORK
37	BELT COVER	102	HEX BOLT M8X20
38	FLAT WASHER 8N	103	VALVE
39	HEX NUT M10	104	PIPE CLAMP
40	HEX NUT M8	105	WATER PIPE
41	HEX BOLT M8X16	106	WATER TANK COVER
42	SHOCK-REDUCING RUBBER BLOCK	107	WATER TANK
43	RUBBER BLOCK	108	WATER TANK FRAME