


HRH0822RE



NO.	DESCRIPTION	NO.	DESCRIPTION
1	DUST CAP	47	CLUTCH GEAR BUSHING
2	LOCKING SLEEVE	48	CLUTCH SLEEVE
3	WASHER $\Phi 24.8 \times \Phi 30.6 \times 0.9$	49	CLUTCH COMPONENT
4	CIRCLIP $\Phi 15$	50	MIDDLE SHAFT
5	STELL BALL HOLDER	51	ROCKER BEARING
6	WASHER $\Phi 21 \times \Phi 32 \times 5$	52	GEAR
7	STELL BALL $\Phi 7.14$	53	PIN
8	RING SPRING FLORIATE WASHER	54	SPRING
9	SPRING	55	HK0812 NEEDLE BEARING
10	FRONT HOUSING	56	SPRING
11	OIL SEAL $\Phi 25 \times \Phi 35 \times 7$	57	BRACKET O-RING $\Phi 62 \times 4$
12	TENSILE SLEEVE	58	BRACKET
13	BEARING 6805	59	BRACKET PRESS PLATE
14	CIRCLIP $\Phi 25.3 \times 1.5$	60	O-RING $\Phi 21.5 \times 2$
15	WASHER $\Phi 36 \times \Phi 27 \times 2$	61	WASHER $\Phi 8 \times \Phi 17 \times 1$
16	SPRING	62	608RS BEARING
17	BIG GEAR	68	ROTOR
18	CLUTCH DISK	69	INSULATION WASHER
19	SCREW ST4.2X35	70	607RS BEARING
20	SPRING	71	WIND GUIDE
21	HK0808 NEEDLE BEARING	72	SCREW ST3.5X14
22	LOCKING BUTTON	73	STATOR
23	MODEL SELECTOR SPRING	74	TERMINAL BOARD
24	MODEL SELECTOR KNOB	75	BEARING COVER
25	O-RING $\Phi 11 \times 2.5$	76	HOUSING
26	MODEL SELECTOR IRON CORE	77	SWITCH CONTACT
27	HANDLE STEEL RING	78	CARBON BRUSH HOLDER
28	T-BOLT	79	COIL SPRING
29	DEPTH GUAGE KNOBS	80	CARBON BRUSH
30	HANDLE SEAT	82	SWITCH
31	DEPTH GUAGE LOCK BOX	83	CORD
32	AUXILIARY HANDLE	85	CORD SLEEVE
33	ROTARY SLEEVE	86	CORD CLAMP
34	PIN $\Phi 2.5 \times 12$	87	SCREW ST4.2X22
35	POSITION-LIMITED SLEEVE OF IMPACT ROD	88	BACK COVER
36	IMPACT ROD	89	M8 NUT
37	IMPACT ROD SLEEVE	90	DEPTH GUAGE
38	DAMPING BUSHING	91	CLUTCH COMPONENT 1
39	CIRCLIP $\Phi 23.8 \times 1.5$	92	CLUTCH COMPONENT 2
40	PISTON	93	CLUTCH COMPONENT 3
41	O-RING $\Phi 13 \times 3$	94	BRACKET BUSHING
42	CYLINDER	97	SCREW ST4.2X16
43	CYLINDER PIN	98	SCREW ST4X16
44	CYLINDER WASHER	99	WOOL FELT
45	CIRCLIP $\Phi 7 \times 0.6$	100	NUT M6
46	CLUTCH GEAR	104	INDUCTOR