




HMF1802

No.	Description	No.	Description
1	Locking bar	31	Bearing
2	Blade holder	32	Washer
3	Spring	33	Weighting block
4	Lock sleeve	34	Middle cover
5	Spring sleeve	35	Screw
6	Moving bar	36	Bearing
7	Dust cover	37	Eccentric shaft
8	Spindle	38	Rotor
9	Bearing	39	Bearing
10	Fork	40	Stator
11	Spring washer	41	Stator rear cover
12	Bearing	42	Screw
13	Round pin	43	Spring
14	Spring	44	Spring holder
15	Limitation block	45	Nut
16	Gearing case	46	Spring
17	Screw	47	Housing-left
18	Gearing case cover	48	Speed regulator
19	Round pin	49	PCB
20	Limitation ball	50	PCB shell
21	Wave washer	51	Battery pin
22	Spring washer	52	Battery foot-left
23	Eccentric block	53	Dust cover
24	Release button	54	Battery foot-right
25	Led cover	55	AV steel
26	Led light	56	AV rubber
27	Screw	57	AV steel
28	Housing-right	58	Screw
29	Switch button	59	Dust pipe
30	Open washer	60	Screw

HMF1802-EX-RU251201