





HSTG7661EL

NO.	DESCRIPTION	NO.	DESCRIPTION
1	upper handle (right)	28	stopper spring
2	panel	29	screw M8x60
3	nut M8	30	long rod
4	right pulley set	31	rivet 4x10
5	bolt M8x40	32	heated handle
6	bolt M6x20	33	left control lever
7	small shaft sleeve	34	jam nut M6
8	pulley	35	short bushing
9	handle seat	36	input wire
10	bolt M8x45	37	switch
11	long cable	38	deflector cable
12	bolt M8x35	39	spring
13	B pin $\varnothing 1.5 \times 25$	40	left pulley seat
14	gear handle lever	41	5# plastic cover
15	nut M10	42	rotating handle
16	gear handle	43	rubber pad
17	deflector handle lever	44	speed control assembly
18	jam nut M6	45	upper handle (left)
19	spring	46	flexible shaft
20	short rod	47	screw M6x10
21	right control lever	48	flat washer 6
22	rubber pad	49	decoration plate for light cover
23	washer 8	50	cover
24	screw M8x150	51	plastic sheet
25	stopper	52	jam nut M6
26	pin	53	LED light
27	cam	54	screw ST3.5x16-F


HSTG7661ELT-ex-RU20230407

HSTG7661EL



NO.	DESCRIPTION	NO.	DESCRIPTION
1	bolt M10x25	47	bolt M8x16
2	handlebar	48	bearing seat
3	handle connecting plate	49	jam nut M8
4	Bolt M10x45	50	ball bearing 6205
5	Bolt M6x16	51	shaft sleeve 25x34x16
6	strut	52	drive gear
7	bolt M6x20	53	14X4.6-6 tubeless tyre,right
8	small shaft sleeve	54	clip
9	pulley seat	55	drive shaft
10	short wire	56	flat key 6x4x45
11	pulley	57	flat key 8x7x22
12	jam nut M6	58	spring pin
13	bolt M8X20	59	shaft sleeve 25x34x6
14	connecting plate	60	bolt M8X30
15	enging plate	61	small tension pulley
16	bolt M8X40	62	small tension plate
17	jam nut M8	63	bolt M8x45
18	engine	64	big tension combination
19	G250 cable hook	65	bushing
20	belt	66	big tension pulley
21	bolt M6X15	67	pad
22	drive wheel	68	tension connector
23	drive pulley 2	69	flat washer; €12
24	washer 8	70	spring washer €13
25	bolt M8X1X30	71	fixing block
26	transmission box assembly	72	spring
27	bolt M6x20	73	support for friction disc
28	shift connector	74	sleeve 13x20x20
29	plastic sleeve	75	bolt M8X16
30	shift fork	76	jam nut M12
31	bolt M6X16	77	brake spring
32	bearing seat	78	rivet 4x12
33	ball bearing 6200	79	brake block
34	circlip 25	80	belt pulley
35	shift bearing	81	bolt M6x20
36	rubber wheel seat	82	delta bearing seat
37	rubber wheel	83	ball bearing 6002
38	sleeve 15x20x15	84	position part
39	small gear	85	B Pin; €1.5X25
40	hexagon shaft	86	reset spring
41	small chain wheel	87	strut
42	sleeve 12x15x8	88	bottom plate for transmission box
43	transit shaft	100	Rubber Wheel assembly
44	chain wheel	101	Friction disc assembly
45	chain 085-32	102	big tension assembly
46	14X4.6-6 tubeless tyre,left	103	small tension assembly


HSTG7661ELT-ex-RU20230407



HSTG7661EL

NO.	DESCRIPTION
1	chute welded
2	washer C8
3	deflector spring
4	strut
5	deflector cable
6	tie
7	sealing plate
8	lower hinge
9	hinge axle
10	rivet 4x10
11	upper hinge
12	deflector welded
13	sealing washer
15	washer for barrier
16	barrier
17	plastic washer
18	cap 6
100	chute assembly


HSTG7661ELT-ex-RU20230407



HSTG7661EL

NO.	DESCRIPTION
1	HOUSING ASSEMBLE (24)
2	SKID SHOE
3	SKID SHOE
4	NUT M8
5	WASHER 8
6	BOLT M8X25
7	BOLT M8X16
8	SHAVE PLATE (24)
9	BEARING COVER
10	NON-STANDARD BEARING
11	SCREW M8X16
13	RIGHT AUGER (24)
14	BOLT M6X25
15	BUSHING
16	FW SEALING RING 22X40X7
17	RIGHT WORM HOUSING
18	OUTPUT SHAFT (24)
19	BOLT M10X15
20	B PINCHCOCK
21	SAFETY BOLT
22	PAPER WASHER
23	BEARING
24	WASHER 22
25	WORM GEAR
26	FLAT KEY B6X6X18
27	BALL BEARING 6001
28	LEFT WORM HOUSING
29	BOLT M6X25
30	JAM NUT M6
31	LEFT AUGER (24)
32	RIGHT SUPPORT
33	WORM SHAFT
34	LEFT SUPPORT
35	SHAFT SLEEVE
36	BALL BEARING 6004
37	BALL BEARING 51104
38	SEALING RING 20X35X7
39	BOLT M6X35
40	FAN
41	SCREW ST4.2X9.5-F
42	SHOVEL SUPPORT
43	PLASTIC WASHER
44	GEAR PLATE
45	GEAR PLATE COVER
46	METAL COVER
47	BOLT M8X25
48	RUBBER RING
49	WASHER
50	JAM NUT M8
51	BELT PULLEY
52	WASHER 11*34*3
53	BOLT M10X25 (LEFT ROTATE)
54	A FLAT KEY 6X6X20
55	ROUND COVER
56	BALL BEARING
57	WASHER FOR BELT PULLEY

engine for HSTG7661EL



engine for HSTG7661EL

NO.	Part No.	DESCRIPTION	NO.	Part No.	DESCRIPTION	NO.	Part No.	DESCRIPTION
1	380140215-0003	Hexagon bolt with flange	34	380620050-0001	Key	67	171600094-0001	Governing spring
2	120220008-0001	Cylinder head cover assy	35	130150054-0001	Connecting rod	68	171610002-0001	throttle return spring
3	380740571-0001	Breather tube	36	380560056-0001	Steel cable baffle ring	69	171590002-0001	Throttle rod
4	120250013-0001	Gasket for cylinder head cover	37	130060031-0001	Piston pin	70	170430060-0001	Carburetor gasket
5	270960014-0001	Spark plug	38	130030160-0001	Piston	71	170440038-0001	Heat insulating pad for carburetor
6	380140336-0001	Hexagon bolt with flange	39	130070142-0001	Piston ring combination	72	170430048-0001	Carburetor gasket
7	380180098-0001	Stud	40	171750001-0001	Components of governor gear	73	170021719-0001	Carburetor
8	180650065-0001	Outlet gasket	41	380370048-0001	Hexagon nut with flange	74	380950188-0001	Pipe clip
9	120080545-0001	Cylinder head	42	380250002-0001	Square head set screw with flat point	75	380750428-0001	Oil tube
10	380140011-0004	Hexagon bolt with flange	43	171620001-0003	Speed regulating bracket	76	170430065-0001	Carburetor gasket
11	160190048-0001	air deflector	44	381350004-0001	Split pin	77	180020680-0001	Air filter
12	380180093-0001	Stud	45	171630001-0001	Speed regulating arm	78	271660054-0001	Stop switch
13	380600117-0001	ocation pin	46	380450531-0001	Flat washer	79	273210001-0003	Switch off key
14	120150193-0001	Gasket for cylinder head	47	110810237-0001	Crankcase body	80	380370048-0003	Hexagon nut with flange
15	140450022-0001	Valve rocker combination	48	380450514-0001	Flat washer	81	180571747-0001	Muffler
16	140710001-0001	Plate, push rod guide	49	110260025-0001	Sealing plug screw	82	380340005-0005	Hexagon nut
17	140670004-0001	Push rod	50	380940346-0001	Cable cleat	83	180960179-0001	Muffler guard shield
18	140690003-0001	Lifter, Valve	51	380650490-0002	Oil seal	84	380140003-0007	Hexagon bolt with flange
19	140020166-0001	Camshaft assy	52	270360110-0001	Components of starting motor	85	110690070-0001	Oil rule combination
20	500550041-0001	Valve Kit	53	380140095-0005	Hexagon bolt with flange	86	170870056-0001	Tank cover
21	140400016-0001	Valve oil seal	54	270920311-0001	COIL ASSY.,IGNNTION	87	170720009-0001	Pouring orifice filter screen combination
22	140340039-0001	Inner spring of valve	55	380140102-0004	Hexagon bolt with flange	88	170501093-0003	Tank
23	140380017-0001	Retainer, valve spring	56	270020150-0001	FLYWHEEL COMP	89	380930023-0001	Location wire nail
24	140320001-0001	Valve adjustment cap	57	160180023-0001	Impeller	90	270210040-0002	Lighting coil combination
25	171680108-0001	Throttle handle combination	58	193590024-0001	Starting disc	91	380200071-0002	Cross recessed pan head screw
26	380140028-0004	Hexagon bolt with flange	59	380370051-0001	Hexagon nut with flange	92	661280017-0001	Power Decorative plates
27	380650491-0001	Oil seal	60	160210092-0001	Fan cover comp.	93	270860047-0001	Mounting bracket for electric device
28	110820121-0001	Crankcase cover	61	193500080-0001	Manual starting components	94	160200057-0001	Side plate
29	110690038-0001	Oil rule combination	62	193560012-0002	Pull rope handle	95	380140171-0004	Hexagon bolt with flange
30	380630137-0002	Bearing	63	380140531-0001	Hexagon bolt with flange	96	380960121-0005	Clip combination
31	110830007-0001	Crankcase cover gasket	64	193490285-0001	Manual starting assembly	97	380620040-0001	Key
32	380600120-0001	ocation pin	65	380140001-0005	Hexagon bolt with flange	98	380600121-0001	ocation pin
33	130290246-0001	crankshaft	66	380850019-0001	Stay stud			