




ДШ-12,ДШ-12К,ДШ-14К,ДШ-18К

NO.	DESCRIPTION	SPEC.	NO.	DESCRIPTION	SPEC.
1	CHUCK SCREW	M5X20	27	THE FIRST PLANET GEAR	
2	CHUCK	10mm	28	THE FIRST PLANET GEAR RING	
3	TORQUE ADJUSTMENT RING		29	MOTOR GEAR	
4	TORQUE ADJUSTMENT NUT		30	PRESS BOARD	Ø34.5XØ12.5X0.5
5	SPRING		31	SCREW	M3X5
6	WASHER		32	MOTOR PRESS BOARD	
7	SPINDLE		33	MOTOR	
8	BEARING 688Z	688	34	PCB	
9	STEEL BALL	Ø4mm	35	SWTICH	
10	PIN	Ø3X30	36	DRITECTION SWITCH	
11	GEAR BOX		37	BUCKLE	
12	BEARING 688Z	688	38	SCREW	ST3X10
13	CIRCLIP	Ø8	39	SCREW BITS HOLDER	13mm
14	THE THIRD PLANETARY GEAR CARRIER		40	SCREW BITS	50mm
15	GEAR RING		41	SPRING	3.2mm
16	WASHER	Ø34XØ29X0.5	42	HOUSING	
17	THE THIRD PLANETARY GEAR		43	SCREW	ST2.9X16
18	THE SECOND PLANETARY GEAR CARRIER		44	ROPE	
19	THE SECOND PLANETARY GEAR		45	MAGNET (ONLY FOR ДШ-14Л,ДШ-18Л)	28X18.5X2
20	TWO SPEED CHANGE GEAR RING		46	BATTERY PACK	
21	PLASTIC GEAR RING		47	CHARGER	
22	SCREW	Ø1.2	888	GEAR BOX ASSEMBLY	
23	SPRING	65Mn			
24	TWO SPEED CHANGE BUTTON	24			
25	SPRING FOR TWO SPEED CHANGE BUTTON				
26	THE FIRST PLANET CARRIER				

DS-12,DS-12C,DS-14C,DS-18C-EX-RUS20200717