



ДШС-181

NO.	DESCRIPTION	NO.	DESCRIPTION
1	CHUCK SCREW	27	THE FIRST PLANET GEAR
2	CHUCK	28	THE FIRST PLANET GEAR RING
3	TORQUE ADJUSTMENT RING	29	MOTOR GEAR
4	TORQUE ADJUSTMENT NUT	30	PRESS BOARD
5	SPRING	31	SCREW
6	WASHER	32	MOTOR PRESS BOARD
7	SPINDLE	33	MOTOR
8	BEARING 688Z	34	INTERNAL CABLE
9	STEEL BALL	35	SWITCH
10	PIN	36	DRITECTION SWITCH
11	GEAR BOX	37	BUCKLE
12	BEARING 688Z	38	SCREW
13	CIRCLIP	39	SCREW BITS HOLDER
14	THE THIRD PLANETARY GEAR CARRIER	40	SCREW BITS
15	GEAR RING	41	SPRING
16	WASHER	42	DECORATION COVER
17	THE THIRD PLANETARY GEAR	43	HOUSING
18	THE SECOND PLANETARY GEAR CARRIER	44	SCREW
19	THE SECOND PLANETARY GEAR	45	ROPE
20	TWO SPEED CHANGE GEAR RING	46	MAGNET (ONLY FOR ДШС-14К, ДШС-18К)
21	PLASTIC GEAR RING	888	GEAR BOX ASSEMBLY
22	SCREW		
23	SHRAPNEL FOR TWO SPEED CHANGE BUTTON		
24	TWO SPEED CHANGE BUTTON		
25	SPRING FOR TWO SPEED CHANGE BUTTON		
26	THE FIRST PLANET CARRIER		

DSS-181-EX-RUS220718